



MacBook Air Models A1237 and A1304 Battery Replacement

Written By: Walter Galan



INTRODUCTION

[video: <http://www.youtube.com/watch?v=Ej6k99wwcak>]

Don't pay Apple to replace your worn out battery. Do it yourself!



TOOLS:


- [Phillips #00 Screwdriver](#) (1)



PARTS:

- [MacBook Air \(Original/Late 2008/Mid 2009\) Battery](#) (1)

Step 1 — Lower Case




- Remove the following 10 screws securing the lower case to the Air:
 - Six 2.8 mm Phillips screws.
 - Two 3.8 mm Phillips screws.
 - Two 5.4 mm Phillips screws.

Step 2



- Slightly lift the lower case near the vents and push it toward the rear of the computer to free the mounting tabs.

Step 3 — Battery



- Disconnect the battery connector by pulling it straight out of its socket.

Step 4



- Remove the following nine screws securing the battery to the Air:
 - Four 2.9 mm Phillips.
 - Four 3.8 mm Phillips.
 - One 7.2 mm Phillips.

Step 5



- Lift the battery out of the Air.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-17 08:20:22 PM.